Door Locks

n Locking the vehicle from inside



- ▶ Inside lock button
- 1 Locks
- 2 Unlocks




- ► Door lock switch Operates all door locks.
- 1 Locks
- 2 Unlocks

n Locking the vehicle from outside

Using the entry function or wireless remote control (\rightarrow P.10, 11)

n Rear door child-protector lock



Pushing down the switch prevents the rear doors from being opened from the inside.

Always set the child protector locks when children are seated in the rear seat.

n Door closer (if equipped)

If a door is left slightly open, it will close automatically.

Power Windows



1 Power window switches

To open: press the switch.

To close: pull the switch up.


Fully pulling up and releasing the switches causes the windows to close fully. Fully pressing down and releasing the switches causes the windows to open fully.

2 Window lock switch

The window lock switch disables the operation of all windows other than the driver's door window.

Moon Roof

n Opening and closing



1 Opens

The moon roof stops slightly before the fully opened position.

To fully open, press the switch again.

2 Closes

$n \ \ Tilting \ up \ and \ down$



- 1 Tilts up
- 2 Tilts down

Fuel Tank Cap



1 Press the fuel filler door opener.



2 Slowly remove the cap by turning it counterclockwise.

After the cap is removed, it can be hung on the inside of the fuel filler door.

Hood



1 Pull the hood release lever.



2 Insert your fingers under the hood, pull the hood catch and lift the hood.

Trunk

n Opening the trunk



▶ Trunk opener

To open the trunk from inside the cabin, simply press the trunk opener.



To disable the trunk opener, turn off the main switch in the glove box.

- 1 On
- 2 Off

When the trunk opener is disabled, the trunk cannot be opened using the wireless remote control or the entry function.

▶ Entry function and wireless remote control (\rightarrow P.10, 11)

n Trunk easy closer

If the trunk lid is left slightly open, it will close automatically.

n Trunk closer switch (if equipped)



Pressing the switch closes the trunk lid automatically.